QUALITY BUILT MEGAPHONE FOR INDOOR / OUTDOOR USE



PRECAUTIONS

- Ensure batteries are inserted the correct way round.
 Align the [-] marks on the batteries with the spring in the back cover.
- Use new batteries whenever possible as sound output is directly related to battery level status.
- Remove batteries from the megaphone when not in use.
- Press the 'Siren' button to activate emergency siren/alarm.

DETAILED TECHNICAL DATA

Power Handling:	10WRMS
Construction Materials:	ABS
Audio Projection Range:	Up to 100 Meters
Battery Operated:	6xAA Type Cells

OPERATING INSTRUCTIONS

- Open the back cover by pressing down on the 'Open' Button.
- Insert 6 x AA batteries then close and lock the back cover.
- To activate the megaphone, press the ON/OFF button on the back cover.
- When using the megaphone place your lips as close as possible to the megaphone when speaking. Adjust the volume to the desired level with out causing any feedback.

Ergonomic Pistol Grip and Light-Weight Chassis

Trusted & Used by U.S.Armed Forces



• Talk, Music, and Siren Switch


For Indoor/Outdoor Use

I

FEATURES

- Dynamic Microphone and High-Quality
- Speaker·Compact, Portable, and Durable
- Built-in Automatic Siren Function
- Adjustable Volume Control

TECHNICAL DRAWING



_ength:	160mm
Width:	100mm
Length Of the Handle:	100mm
Weight Approx :	0.32Kg