



### Controls



### Connections



- ① High pass filter frequency. This is used to cut out lower frequencies sent to the speakers
- ② Low pass filter frequency. This is used to cut out higher frequencies sent to the speakers.
- ③ Gain control. Used for level matching the amplifier to your source unit. This is not a volume control.
- ④ EQ boost. This is to adjust the bass level relative to the rest of the frequency range. WARNING if used you will need to reset the gain downwards to accommodate the adjustment.
- ⑤ Remote. This is the connection for the external level controller.
- ⑥ Clip indicator. This light is to show when the amplifier is clipping. If you see it light up then you will need to turn the gain down.
- ⑦ Speaker connection. This is the output to the speaker load.
- ⑧ Power supply section. Connect +12V to batteries, GND to earth and use a switched 12v supply to REM to switch the amplifier on and off.