ULTIMATE GRADE SOUND QUALITY TWEETER OPTIMIZED FOR CUSTOM INSTALLATIONS




INSTALLATION POINTS

Failure to observe any of these installation points will invalidate your warrantv:

- Included is a capacitor to give a 5000Hz crossover point. This must be installed in the positive feed to the tweeter. Failure to use a high pass corssover like this will result in NON WARRANTABLE damage on the first use.
- When setting up a system ensure to listen carefully for signs of distortion. Amplifier clipping damages tweeters very quickly. Always make sure to have enough power to drive speakers cleanly at your desired listening level.

SPL VS FREQUENCY



DETAILED TECHNICAL DATA

ver Handling (Per Driver):	45 WRMS (@0%Thd)
minal Impedance:	4 ohm
ce Coil Diameter:	25.4 mm
phragm Material:	Silk
gnet Type:	N40 NEO
nsivitity(1m/w):	91dB
quency Response:	1.5KHz-24KHz

TEAM TIPS

• If you are an advanced user using an active crossover instead of the capacitor please pay attention to the SPL graph below and tune the system carefully. Remember that power handling of a tweeter drops dramatically as you lower the crossover point. It is hard to give a lower bound limit on crossover point because it depends on many factors. Tweeters pushed low and hard will fail and damage is also NDN WARRANTABLE.



TECHNICAL DRAWING

Mounting Depth:	19mm
Mounting Diameter:	50mm
Total Diameter:	60mm
Weight Approx. (Per a Driver):	0.115Kg

